

# 1B UNA FONT WITH UNDERCOUNTER BOILERS



1B UNA FONT 1000859		DIMENSIONS	SYSTEM SET-UP
<p>&gt; Space-saving countertop font</p>		<p>&gt; Vacuum insulated tank for up to 70% more energy-efficiency</p>	

MIX UC3 1000880	MIX UC8 1000887	OPTIONAL - DRIP TRAY 2300268
	OR	

FONT

NAME ORDER CODE	DIMENSIONS INCL. DRIP TRAY (D x W x H mm)	DIMENSIONS EXCL. DRIP TRAY (D x W x H mm)	TAP TO COUNTER (T mm)
1b Una Font 1000859	168 x 120 x 287	138 x 30 x 287	233

BOILERS

PRODUCT INFO NAME ORDER CODE	WATER TYPE ADJUSTABLE TEMP	SIZE DIMENSIONS DIMENSIONS (D x W x H mm)	PERFORMANCE SPECS			PLUMBING & ELECTRICAL REQS	
			IMMEDIATE DRAW OFF	L/HR	CUPS /HR	POWER @220v	PLUMBING REQS
MIX UC3 1000880	Y	385 x 210 x 444	3L	28L	156	2.8kW	3/4" BSP
MIX UC8 1000887		385 x 210 x 617	8L				

PACKAGING

NAME ORDER CODE	PACKAGING DIMENSIONS (L x W x H mm)	PACKED WEIGHT	QTY / PALLET
1b Una Font 1000859	290 x 570 x 215	1.65kg	30
MIX UC3 1000880	450 x 290 x 540	11kg	18
MIX UC8 1000887	450 x 290 x 700	14kg	24



1 BUTTON UNA FONT WITH MIX UC3/UC8		1b UNA FONT 1000859	
COUNTER CUT-OUT WITH DRIP TRAY	MIX UC3 1000880	MIX UC8 1000887	
		<p>* Hosing should be trimmed to ensure continuous drop from font to boiler</p>	<p>* Hosing should be trimmed to ensure continuous drop from font to boiler</p>
	<ul style="list-style-type: none"> <li>&gt; Connect the hose to the inlet valve of the boiler. Make sure a sealing washer is fitted.</li> <li>&gt; Turn on water and check for leaks.</li> </ul>		
<p><b>VENTILATION REQUIREMENTS</b></p> <p>50mm/1.9" clearance required at each side and back of machine if installed in an enclosed cabinet.</p>	<p><b>OPERATING BOILER FOR THE FIRST TIME</b></p> <ul style="list-style-type: none"> <li>&gt; Check that all installation procedures have been carried out.</li> <li>&gt; Ensure water valve is on.</li> <li>&gt; Plug boiler into suitable socket.</li> <li>&gt; Turn on the power switch.</li> <li>&gt; The "Wait" progress circle will be visible on the screen and the machine will fill to a safe level, above the elements, before heating.</li> <li>&gt; The "Ready" tick will come up on screen when the machine is full and up to normal operating temperature (approx. 10/20 mins).</li> <li>&gt; The boiler is now ready for use - the display will show the button settings and the "Ready" status tick.</li> <li>&gt; The boiler may now be used to dispense Hot Water to the preset factory settings.</li> </ul>		
<p><b>ELECTRICAL INSTALLATION PROCEDURE</b></p> <p>When installing the machine, always observe the local regulations and standards. The standard machine is supplied with a UK 3-pin plug. For EU models a 2-pin CEE-7 plug will be supplied. US models will be supplied with the suitable plug. A suitable mains power supply socket should be available within easy access of the appliance so that it can be disconnected easily after install.</p>	<p><b>NOTE:</b> Because the boiler is electronically controlled no priming is necessary. The element cannot switch on until a safe level of water is reached.</p>		
<p><b>PLUMBING INSTALLATION PROCEDURE</b></p> <ul style="list-style-type: none"> <li>&gt; Ensure that the equipment is installed according to local plumbing &amp; water regulations.</li> <li>&gt; Mains water pressure required (limits): 14.5 - 145psi (100 - 1000kPa, 0.1 - 1MPa).</li> <li>&gt; Requires inline water filter within your water specifications.</li> <li>&gt; The machine is supplied with a 3/4" BSP connection.</li> <li>&gt; Turn on the water to flush any impurities, dust etc from the inlet hose and water pipe. Allow several litres through, especially for new installations.</li> </ul>			